



Actualize

Task Controls



PULL UP
& HOLD



PULL UP
& HOLD

Seat Height


Control Location: Right hand side of the chair

To adjust the height of the chair, pull the large inside lever upwards and release when at the desired height. If the user is sitting on the chair, the seat will go down. Remove the weight from the seat to adjust the seat up.


Seat Depth (Optional)

Control Location: Left hand side of the chair

To adjust the seat depth of the chair, lift upwards the large inside lever and hold. Slide the seat forwards/ backwards. Release the lever to lock into position.



PULL UP



Back Lock & Tension

Control Location: Left hand side (lock) & right hand side (tension). To activate the back lock, turn the small knob upwards. To release the back lock, turn the knob downwards. Adjust the 3 tension settings by turning the right hand outer knob upwards/ downwards. Upwards = most resistance. Downwards = least resistance.


Lumbar Support (Mesh Back Chairs Only)

Control Location: Back of the chair


Use both hands to pull up the back up to 100mm in 20mm increments. To return the back to the min. height, push it to the very top of the mechanism and release back down. Rotate the dial counter-clockwise to extend the lumbar by up to 10mm. Rotate clockwise to retract.

Actualize

Task Controls



PUSH



Armrest Height


Control Location: Outside of arms

To adjust the arm height up or down, push the button in, move the arm upwards/downwards and release when at the desired height.

Armrest Slide (Optional)

Control Location: Arm pads

To adjust the armrests forwards/ backwards, simply slide the top of the arm pads. This is best done while the user is sitting in the chair.



Armrest Rotation (Optional)

Control Location: Arm Pads

To rotate the arm pads, twist the arm pads inwards and outwards as desired. This is best done while the user is sitting in the chair.